

A must for all opticians who place value on comfortable working and good design.

This device shows competence and is perfect for working in the sales area. The OPTIFORMA can be built into the service desk. Frames can be heated in almost total silence. A digital temperature and time setting for gentle processing of sensitive materials is an expression of a genuine quality product made in Germany.



OPTIFORMA Profi

- Quiet running
- Stepless temperature and time setting via LCD and keys
- Menu driven handling
- Installed overheat protection
- Auto cut out if unit is knocked over in case of device inclination
- Automatic cooling phase
- Can be built into work bench or service desk, installation depth: 145 mm
- Including a template to use on a work top with a max. of 28 mm thickness
- Distance between the air jets: 45 mm
- Including spot heating jet

 Black/Grey


120 3184
2872 01

Template for OPTIFORMA Profi No. 120 3184

120 3190
2872 25

Technical data

Temperature scale:	60 to 140 °C
Adjustable operating time:	50 to 249 s
Overheating protection through thermo switch	
Power:	800 W
Power usage per 10 min:	0.1333 kWh
Voltage:	230 V
Size (w x h x d):	230 x 228 x 275 mm
Weight:	2.1 kg

 **36 month warranty!**

 For **spare parts** contact your local distributor.